

## Wall Mounting Instructions

Place your level or straight edge between the two points marked 'A' as per the diagram below. Mark these points onto your level or straight edge. This will provide exact centre marks for drilling. Transfer the marks to your desired fixing location. Drill holes using correct size masonry drill bit for wall plugs & fixings. Into solid wall / Red wall plug = 6mm masonry drill bit / Brown wall plug = 7mm masonry drill bit. Install wall plugs and screws as described.... to ensure a good fixing adjust the screw heads in and out as required.

